
## How to configure SIMHUB for SenseForce usage: Sound Output






channel 1 +2 SenseForce 2D/3D

channel 3 +4 SenseForce 3D

## How to configure SIMHUB for SenseForce usage: Effects Profile





Select Pad zones

