

M8 Upgrade instructions

Method 1: Automatic upgrade

1, When the M8 is off, Connect to the computer USB3.0 interface with the USB cable inside the box



2, In my computer, there will be a U disk.



Toolkit (F:)

3, Double-click the **Automatic upgrade** file in the current folder.



**Automatic
upgrade**

4, In the open window, follow the prompts to complete the upgrade.

Method 2: Manual upgrade

1, When the M8 is off, Connect to the computer USB3.0 interface with the USB cable inside the box



2, In my computer, there will be a U disk.



Toolkit (F:)

3, Open the U disk, delete the app.upg file



app.upg

4, Copy the app.upg upgrade file from this directory. After the transfer is completed, the upgrade is completed. Unplug the USB.

M8 升级说明

方法一：自动升级

1, M8 关机状态下，用包装盒内的 USB 线，连接到电脑 USB3.0 接口



2, 我的电脑里，会有一个 U 盘出现。



Toolkit (F:)

1, 双击当前文件夹内 **自动升级** 文件。



自动升级.

2, 在打开窗口根据提示信息，完成升级。

方法二：手动升级

1, M8 关机状态下，用包装盒内的 USB 线，连接到电脑 USB3.0 接口



2, 我的电脑里，会有一个 U 盘出现。



Toolkit (F:)

3, 打开 U 盘，删除 app.upg 文件



app.upg

4, 将本目录 app.upg 升级文件复制进去。待传输完成，升级就完成。拔掉 USB 即可。