



Caution:



Caution:

The Mover contains two Neodymium magnets with a holding power of 2.7 kg. (26.5N)

Keep safely away from magnetic strips such as credit cards, and pacemakers, etc.

We recommend at least 25 mm.

Be sure to follow these safety precautions.



User Manual:

Model: Easy

The Mover is designed to roll on walkways, roads, etc. For transitions, such as moving from the street to a sidewalk, lift skis up briefly to avoid damage to the Mover or the skis. It is not permitted to transport skis on a roof rack with the Mover still attached.

For proper installation see pictures below:

Beware: Ski 1 right hand, the second ski is pushed into the stopper of the binding.

Fasten Mover to ski 1. Then use the included elastic cord and pull according to instructions up to the binding (ski 2) then pull the cord over the binding. Be sure not to cross the elastic cord.

The included loop and hook fasteners are utilized to attach the ski poles to the skis, ideal for longer transports.

After use, rinse the Mover with lukewarm water, disassemble, lay out and allow to dry completely, then store in the provided storage bag. From time to time, add a drop of lubricating oil between the axle and wheel.

Disposal:

You may send the Mover back to us. We will disassemble it and safely dispose of and/or recycle all components.

