COUNTERS EC




- Continue by placing the collar.
- Finish construction by covering the collar with the top desk.



- When using the ECcounter with doors DO NOTcarry the counter by holding the top desk. Before dismantling the counter releaseALL the sliding bolts.
- When packing always fold the sides inwards so they are on the inside of the counter.


EUROcounters **EC**


instruction manual




 If a logo is included, place the logo support into the holes in the desk and place the logo on the completed EC counter.









- Removethestructurefrom thepackaging,

one placed on the floor.

followed by the top.

open the structure so that the rubber feet

- Unwrap the shelves,if included, and place

into the counter. First the bottom shelf

- Place the top desk so that the marked side is at the bottom.

EUROcounter EC-1



Max. load of table: 40 kg Max. load of table with wheels: 30 kg Max. load of shelf: 10 kg

EUROcounter EC-3



Max. load of table: 35 kg Max. load of table with wheels: 25 kg Max. load of shelf: 8 kg

EUROcounter EC-5



Max. load of table: 40 kg Max. load of table with wheels: 30 kg Max. load of shelf: 8 kg

EUROcounter EC-2



Max. load of table: 40 kg Max. load of table with wheels: 30 kg Max. load of shelf: 10 kg

EUROcounter EC-4



Max. load of table: 35 kg Max. load of table with wheels: 25 kg Max. load of shelf: 8 kg


EUROcounter EC-6



Max. load of table: 40 kg Max. load of table with wheels: 30 kg Max. load of shelf: 8 kg

Exchanging be graphic panel:

- Take out the plastic profile as showinginthe picture, undo both screwsfrom the horizontal panel with the imbuskey. take off the panels, replace the horizontal profile, screwin the screwsto fix the inner panel and fix the panel with plastic profile. (seethe picture)



Notice: For interior use only!

packaging



Flight bag for ECcounter.

-1-- 3 -- 4 -