



Caution:

The Mover contains two Neodymium magnets with a holding power of 2.7 kg. (26.5N)

Keep safely away from magnetic strips such as credit cards, and pacemakers, etc.

We recommend at least 25 mm.

Be sure to follow these safety precautions.

User Manual:

Model: Traveler

The Mover is designed exclusively to transport (roll) skis (max weight 18 kg). See pictures below for proper installation.

Tuck the MoverBody into the ends of the skis. Ensure that the hook and loop fastener is in between the ski and the Mover (see picture). Take the loop and hook fastener according to picture and wrap it tightly around the Mover and the ends of the skis. Ensure that the hook and loop fastener is tightly closed around the Mover and the skis. Now insert the hub and attach the wheels.

The Mover is designed to roll skis on walkways, streets, etc. To prevent damage, it is recommended that skis are lifted off the ground when moving them across transitions, such as going from the road onto a sidewalk.

After use, rinse the Mover with lukewarm water, disassemble and let dry completely.

Disposal:

You may send the Mover back to us. We will disassemble it and safely dispose of and/or recycle all components.

