


I'm not robot  reCAPTCHA

I am not robot!

Viva self cleaning hidden bottle water cooler manual

Viva self clean water dispenser. Viva self clean. Viva self cleaning hidden bottle water cooler.

Hot and Cold Bottled Water Cooler Model # 7LIECH-SC-SSF USER MANUAL TO REDUCE THE RISK OF INJURY AND PROPERTY DAMAGE, USER MUST READ THIS MANUAL BEFORE ASSEMBLING, INSTALLING & OPERATING DISPENSER. SAVE FOR FUTURE USE IMPORTANT: Do NOT Return Dispenser To Store.



Do not use an adapter. Do not use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. A 120 volt, 60 Hz., AC only, 15 amp, fused electrical supply is required. A time-delay fuse or circuit breaker is recommended. Do not overload the circuit, provide separate circuit, if required, to serve only this appliance. TABLE OF CONTENTS Safety Precautions 2 Safety Precautions-Electrical Requirements 3 4 . Key Information for Future Use 5 Specifications 5 .. Parts & Features 6 Assembly Cleaning prior to initial use . Installation Installing the Correct Bottle Receptacle . 7 . 8 9 ... Operation .. 10 Proper Care & Cleaning . 11 Troubleshooting 12 Limited Warranty 13 KEY INFORMATION FOR FUTURE USE Please register your dispenser immediately at www.electrotemp.com. SPECIFICATIONS Power Supply 4.5 AMP Refrigerant Type R-134A Cold Water Power 100 Watts Cold Capacity / Peak Hour 1.0 Gallon / 3.79 L Cold Temp Range 3°C - 10°C / 37.4°F - 50°F Hot Water Power 425 Watts Hot Capacity / Peak Hour 1.0 Gallon / 3.79 L Hot Temp Range 80°C - 92°C / 176°F - 197.6°F Dimensions 91.3 H x 27.5 W x 28.6 D (cm) 35.4 H x 10.8 W x 11.3 D (inch) Net Weight 27.9lbs/12. ASSEMBLY To prevent accidental tip hazard, base supplied must be securely fixed to the dispenser as shown. Do NOT operate dispenser without base properly installed. Keep plastic bags away from children. 1. Remove dispenser from packaging. 2.



Failure to execute the instructions in this manual can cause personal injury or property damage. This product dispenses water at very high temperatures. Failure to use properly can cause personal injury. SAFETY PRECAUTIONS --- Electrical Requirements Electrical Shock Hazard Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter. Do not use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. A 120 volt, 60 Hz., AC only, 15 amp, fused electrical supply is required. A time-delay fuse or circuit breaker is recommended. Do not overload the circuit, provide separate circuit, if required, to serve only this appliance. TABLE OF CONTENTS Safety Precautions 2 Safety Precautions-Electrical Requirements 3 4 . Key Information for Future Use 5 Specifications 5 .. Parts & Features 6 Assembly Cleaning prior to initial use . Installation Installing the Correct Bottle Receptacle . 7 . 8 9 ... Operation .. 10 Proper Care & Cleaning . 11 Troubleshooting 12 Limited Warranty 13 KEY INFORMATION FOR FUTURE USE Please register your dispenser immediately at www.electrotemp.com. SPECIFICATIONS Power Supply 4.5 AMP Refrigerant Type R-134A Cold Water Power 100 Watts Cold Capacity / Peak Hour 1.0 Gallon / 3.79 L Cold Temp Range 3°C - 10°C / 37.4°F - 50°F Hot Water Power 425 Watts Hot Capacity / Peak Hour 1.0 Gallon / 3.79 L Hot Temp Range 80°C - 92°C / 176°F - 197.6°F Dimensions 91.3 H x 27.5 W x 28.6 D (cm) 35.4 H x 10.8 W x 11.3 D (inch) Net Weight 27.9lbs/12. ASSEMBLY To prevent accidental tip hazard, base supplied must be securely fixed to the dispenser as shown. Do NOT operate dispenser without base properly installed. Keep plastic bags away from children. 1. Remove dispenser from packaging. 2.



PN 7LIECH-SC-SS® © 2012 Electrotamp Technologies Inc.SAFETY PRECAUTIONS To reduce risk of injury and property damage, user must read this entire manual before assembling, installing & operating dispenser. Failure to execute the instructions in this manual can cause personal injury or property damage. This product dispenses water at very high temperatures. Failure to use properly can cause personal injury.SAFETY PRECAUTIONS ---- Electrical Requirements Electrical Shock Hazard Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter. Do not use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. A 120 volt, 60 Hz., AC only, 15 amp, fused electrical supply is required. A time-delay fuse or circuit breaker is recommended. Do not overload the circuit, provide separate circuit, if required, to serve only this appliance.TABLE OF CONTENTS Safety Precautions 2 Safety Precautions-Electrical Requirements 3 4 . Key Information for Future Use 5 Specifications 5 . Parts & Features 6 Assembly Cleaning prior to initial use . Installation Installing the Correct Bottle Receptacle . 7 . 8 9 ... Operation .. 10 Proper Care & Cleaning . 11 Troubleshooting 12 Limited Warranty 13 KEY INFORMATION FOR FUTURE USE Please register your dispenser immediately at www.electrotamp.SPECIFICATIONS Power Supply 4.5 AMP Refrigerant Type R-134A Cold Water Power 100 Watts Cold Capacity / Peak Hour 1.0 Gallon / 3.79 L Cold Temp Range 3°C - 10°C / 37.4°F - 50°F Hot Water Power 425 Watts Hot Capacity / Peak Hour 1.0 Gallon / 3.79 L Hot Temp Range 80°C - 92°C / 176°F - 197.6°F Dimensions 91.3 H x 27.5 W x 28.6 D (cm) 35.4 H x 10.8 W x 11.3 D (inch) Net Weight 27.9lbs/12.ASSEMBLY To prevent accidental tip hazard, base supplied must be securely fixed to the dispenser as shown. Do NOT operate dispenser without base properly installed. Keep plastic bags away from children. 1. Remove dispenser from packaging. 2. Lay dispenser on its back. 3. Position cooler upright. Unpack drip tray and insert into dispenser. 4. Properly dispose all of packaging. 7. C IMPORTANT: Do NOT Return Dispenser To Store.CLEANING PRIOR TO INITIAL USE To remove any odors or dust that may collect during shipment, you must clean dispenser prior to first use. DO NOT PLUG THE COOLER INTO AN ELECTRICAL POWER OUTLET Time Required: 40 minutes. 1. Remove bottle receptacle by turning it counter clockwise and pulling up. Store in a safe place. 2. Remove plastic baffle from inside reservoir. Clean with warm soapy water, rinse, then store in a safe place. 3.INSTALLATION To prevent accidental tip hazard, dispenser must be securely anchored to wall as shown. 1. Place dispenser upright. 2. Locate dispenser on a hard and level surface in a cool shaded location near a grounded wall outlet. Notice: Do NOT plug in power cord yet. 3. Position dispenser so the back is at least 4 inches from wall and there are at least 4 inches of clearance on both sides. 4. Install Wall Mount Strap to prevent accidental tip over: • Unclip strap from back of dispenser.INSTALLING THE CORRECT BOTTLE RECEPTACLE Then Use This Bottle Receptacle If Your Water Bottle Looks Like 1. 3. Remove bottle receptacle (1) by turning it counter clockwise and pulling up. Remove Collar (2) from foam packaging or bag at front of dispenser. Align tabs. 4.OPERATION This unit is intended for water dispensing only. Do NOT use other liquids. Do NOT use for other purposes. Warranty is void if used for any other liquids including coffee, tea, juices, beer or wine. This dispenser has been designed to use water bottles with 3 & 5 gallon capacity. Do NOT use alternative bottles. Initial Set Up Notice: To prevent damage to compressor, allow unit to sit upright for at least 4 hours prior to operating. 1. Remove tamper seal from bottle cap. Do NOT remove plastic cap.PROPER CARE & CLEANING General Cleaning Perform: As needed Time Required: 5 minutes. Note: Do NOT use abrasive materials or chemical cleaners. 1. Clean cabinet surfaces with a soft cloth and warm soapy water, then rinse. 2.



Do not use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. A 120 volt, 60 Hz., AC only, 15 amp, fused electrical supply is required. A time-delay fuse or circuit breaker is recommended. Do not overload the circuit, provide separate circuit, if required, to serve only this appliance.TABLE OF CONTENTS Safety Precautions 2 Safety Precautions-Electrical Requirements 3 4 . Key Information for Future Use 5 Specifications 5 . Parts & Features 6 Assembly Cleaning prior to initial use . Installation Installing the Correct Bottle Receptacle . 7 . 8 9 ... Operation .. 10 Proper Care & Cleaning . 11 Troubleshooting 12 Limited Warranty 13 KEY INFORMATION FOR FUTURE USE Please register your dispenser immediately at www.electrotamp.SPECIFICATIONS Power Supply 4.5 AMP Refrigerant Type R-134A Cold Water Power 100 Watts Cold Capacity / Peak Hour 1.0 Gallon / 3.79 L Cold Temp Range 3°C - 10°C / 37.4°F - 50°F Hot Water Power 425 Watts Hot Capacity / Peak Hour 1.0 Gallon / 3.79 L Hot Temp Range 80°C - 92°C / 176°F - 197.6°F Dimensions 91.3 H x 27.5 W x 28.6 D (cm) 35.4 H x 10.8 W x 11.3 D (inch) Net Weight 27.9lbs/12.ASSEMBLY To prevent accidental tip hazard, base supplied must be securely fixed to the dispenser as shown. Do NOT operate dispenser without base properly installed. Keep plastic bags away from children. 1. Remove dispenser from packaging. 2. Lay dispenser on its back. 3. Position cooler upright. Unpack drip tray and insert into dispenser. 4. Properly dispose all of packaging. 7. C IMPORTANT: Do NOT Return Dispenser To Store.CLEANING PRIOR TO INITIAL USE To remove any odors or dust that may collect during shipment, you must clean dispenser prior to first use. DO NOT PLUG THE COOLER INTO AN ELECTRICAL POWER OUTLET Time Required: 40 minutes. 1. Remove bottle receptacle by turning it counter clockwise and pulling up. Store in a safe place. 2. Remove plastic baffle from inside reservoir. Clean with warm soapy water, rinse, then store in a safe place. 3.INSTALLATION To prevent accidental tip hazard, dispenser must be securely anchored to wall as shown. 1. Place dispenser upright. 2. Locate dispenser on a hard and level surface in a cool shaded location near a grounded wall outlet. Notice: Do NOT plug in power cord yet.



This product dispenses water at very high temperatures. Failure to use properly can cause personal injury.SAFETY PRECAUTIONS ---- Electrical Requirements Electrical Shock Hazard Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter. Do not use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. A 120 volt, 60 Hz., AC only, 15 amp, fused electrical supply is required. A time-delay fuse or circuit breaker is recommended. Do not overload the circuit, provide separate circuit, if required, to serve only this appliance.TABLE OF CONTENTS Safety Precautions 2 Safety Precautions-Electrical Requirements 3 4 . Key Information for Future Use 5 Specifications 5 . Parts & Features 6 Assembly Cleaning prior to initial use . Installation Installing the Correct Bottle Receptacle . 7 . 8 9 ... Operation .. 10 Proper Care & Cleaning . 11 Troubleshooting 12 Limited Warranty 13 KEY INFORMATION FOR FUTURE USE Please register your dispenser immediately at www.electrotamp.SPECIFICATIONS Power Supply 4.5 AMP Refrigerant Type R-134A Cold Water Power 100 Watts Cold Capacity / Peak Hour 1.0 Gallon / 3.79 L Cold Temp Range 3°C - 10°C / 37.4°F - 50°F Hot Water Power 425 Watts Hot Capacity / Peak Hour 1.0 Gallon / 3.79 L Hot Temp Range 80°C - 92°C / 176°F - 197.6°F Dimensions 91.3 H x 27.5 W x 28.6 D (cm) 35.4 H x 10.8 W x 11.3 D (inch) Net Weight 27.9lbs/12.ASSEMBLY To prevent accidental tip hazard, base supplied must be securely fixed to the dispenser as shown. Do NOT operate dispenser without base properly installed. Keep plastic bags away from children. 1. Remove dispenser from packaging. 2. Lay dispenser on its back. 3. Position cooler upright. Unpack drip tray and insert into dispenser. 4. Properly dispose all of packaging. 7. C IMPORTANT: Do NOT Return Dispenser To Store.CLEANING PRIOR TO INITIAL USE To remove any odors or dust that may collect during shipment, you must clean dispenser prior to first use. DO NOT PLUG THE COOLER INTO AN ELECTRICAL POWER OUTLET Time Required: 40 minutes. 1. Remove bottle receptacle by turning it counter clockwise and pulling up. Store in a safe place. 2. Remove plastic baffle from inside reservoir. Clean with warm soapy water, rinse, then store in a safe place. 3.INSTALLATION To prevent accidental tip hazard, dispenser must be securely anchored to wall as shown. 1. Place dispenser upright. 2. Locate dispenser on a hard and level surface in a cool shaded location near a grounded wall outlet. Notice: Do NOT plug in power cord yet. 3. Position dispenser so the back is at least 4 inches from wall and there are at least 4 inches of clearance on both sides. 4. Install Wall Mount Strap to prevent accidental tip over: • Unclip strap from back of dispenser.INSTALLING THE CORRECT BOTTLE RECEPTACLE Then Use This Bottle Receptacle If Your Water Bottle Looks Like 1. 3. Remove bottle receptacle (1) by turning it counter clockwise and pulling up. Remove Collar (2) from foam packaging or bag at front of dispenser. Align tabs. 4.OPERATION This unit is intended for water dispensing only. Do NOT use other liquids. Do NOT use for other purposes. Warranty is void if used for any other liquids including coffee, tea, juices, beer or wine. This dispenser has been designed to use water bottles with 3 & 5 gallon capacity. Do NOT use alternative bottles. Initial Set Up Notice: To prevent damage to compressor, allow unit to sit upright for at least 4 hours prior to operating. 1. Remove tamper seal from bottle cap. Do NOT remove plastic cap.PROPER CARE & CLEANING General Cleaning Perform: As needed Time Required: 5 minutes. Note: Do NOT use abrasive materials or chemical cleaners. 1. Clean cabinet surfaces with a soft cloth and warm soapy water, then rinse. 2. Wipe dust from back of dispenser to improve efficiency. 3. Remove drip tray assembly by pulling it forward. Remove cover. Place tray and cover in dishwasher or wipe parts clean with a soft cloth and warm soapy water.TROUBLESHOOTING Dispenser does not operate. • Make sure the power cord is properly connected to a working outlet. Water is leaking. • Call 855-VIVA-111 for assistance. Push buttons are stuck and/or faucets are leaking. • Apply mineral oil (baby oil) to button slides to reduce friction. No water is coming from the taps. • Make sure the bottle is not empty. • Make sure to push the water controls in fully. • Remove bottle receptacle as per page 6 step 1.LIMITED WARRANTY Electrotamp Technologies Inc., ("Vendor") warrants to the original purchaser of this dispenser, and to no other person, that if this dispenser is assembled and operated in accordance with the printed instructions accompanying it, then for a period of one (1) year from the date of purchase, all parts in such dispenser shall be free from defects in material and workmanship. Vendor may require reasonable proof of your date of purchase from an authorized retailer or distributor.版本号 修订 A 修订内容 对应铭牌, 重量由13.1Kg更改为12. Page 2INSTALLATION To prevent accidental tip hazard, dispenser must be securely anchored to wall as shown. 1. Place dispenser upright. 2. Locate dispenser on a hard and level surface in a cool shaded location near a grounded wall outlet. Notice: Do NOT plug in power cord yet. 3. Position dispenser so the back is at least 4 inches from wall and there are at least 4 inches of clearance on both sides. 4. Install Wall Mount Strap to prevent accidental tip over: • Unclip strap from back of dispenser. • Mount strap 25 inches up from floor directly to wall stud with screw (See illustration A) If stud is not available, insert and turn anchor directly into sheet rock using a Phillips screwdriver (DO NOT drill hole into sheet rock first when using this anchor). Secure strap by installing screw through washer, the eyelet in strap and into wall mounted anchor. (See illustration B) • Position cooler in place. • Clip strap onto back of cooler to right or left side. (See illustration C). • Adjust length of strap so the dispenser can NOT move forward. Note - Dispenser can be positioned in a corner but still requires Wall Mount Strap to be installed. Lengthen strap so that once installed the dispenser cannot move forward. IMPORTANT: Do NOT Return Dispenser To Store. If you have a question or problem, please contact 855-VIVA-111 for assistance. 8Page 3INSTALLING THE CORRECT BOTTLE RECEPTACLE This model comes set up with a Probe Receptacle (1). No changes are required. The Probe will push the Plug out of the way when you place the bottle into the receptacle. 1. Remove bottle receptacle (1) by turning it counter clockwise and pulling up. 2. Remove Collar (2) from foam packaging or bag at front of dispenser. 3. Align tabs. If Your Water Bottle Looks Like Then Use This Bottle Receptacle If Your Water Bottle Looks Like Then Use This Bottle Receptacle. 4.OPERATION This unit is intended for water dispensing only. Water is leaking. • Call 855-VIVA-111 for assistance. Push buttons are stuck and/or faucets are leaking. • Apply mineral oil (baby oil) to button slides to reduce friction. No water is coming from the taps. • Make sure the bottle is not empty. • Make sure to push the water controls in fully. • Remove bottle receptacle as per page 6 step 1. Turn energy saving switch on back of dispenser to ON. This switch controls the heating of water. If you do not want hot water, turn this switch OFF. Initial Rinsing of Water Lines This unit has been tested and sanitized prior to packing and shipping. During transit dust and odors can accumulate in the tank and lines. You must dispense and dispose at least one quart of water prior to drinking any water. Dispense Cold Water Note: After setup, it will take 1 hour to get water to maximum cold temperature. During this time the compressor will run continuously. 1. Position bottle, glass, pitcher or cooking pot securely below cold water tap. - The circular shapes in the drip plate help align the flow of water. This unit dispenses water at a fast rate. To avoid splashes, hold cup as close to the tap as possible. 2. Depress cold water control downward to start flow. 3. Release cold water control once desired fill level is achieved. IMPORTANT: Do NOT Return Dispenser To Store. If you have a question or problem, please contact 855-VIVA-111 for assistance. 10Page 5PROPER CARE & CLEANING General Cleaning Perform: As needed Time Required: 5 minutes. Note: Do NOT use abrasive materials or chemical cleaners. 1. Clean cabinet surfaces with a soft cloth and warm soapy water, then rinse. 2. Wipe dust from back of dispenser to improve efficiency.

3. Remove drip tray assembly by pulling it forward. Remove cover. Place tray and cover in dishwasher or wipe parts clean with a soft cloth and warm soapy water. Cleaning Cold Reservoir and Water Lines Perform: Every 3 months or whenever an off-taste occurs. Time Required: 15 minutes. Note: Best to do prior to loading a fresh bottle. 1. Turn energy saving switch OFF. 2. Unplug power cord from wall outlet. 3. Remove water bottle. 4. Unclip Wall Mount Strap from back of dispenser and turn dispenser around so backside is facing away from the wall. 5. Place a 2 gallon or larger bucket under the drain plug in the rear of the dispenser. Remove drain cap and silicon plug. Cold water will immediately flow into the bucket. This will be followed several seconds later by hot water at temperatures that can cause severe burns. Avoid direct contact with hot water. Keep children and pets away while draining unit. Reminder - Place drain cap and silicon plug in a safe location so they are not lost. IMPORTANT: Do NOT Return Dispenser To Store. If you have a question or problem, please contact 855-VIVA-111 for assistance. 11Page 6TROUBLESHOOTINGDispenser does not operate. • Make sure the power cord is properly connected to a working outlet. Water is leaking.

- Call 855-VIVA-111 for assistance. Push buttons are stuck and/or faucets are leaking.
- Apply mineral oil (baby oil) to button slides to reduce friction. No water is coming from the taps. • Make sure the bottle is not empty. If so replace it. • Make sure to push the water controls in fully. • Remove bottle receptacle as per page 6 step 1. Shake bottle receptacle vigorously for a few seconds then replace. Cold water is not cold. • It takes up to one hour after setup to dispense cold water. • Make sure the back of the dispenser is at least 4 inches from a wall and there is free airflow on all 4 sides of the dispenser. • Make sure tank is not overfilled. Dispense water until bubbles appear in bottle. • Adjust thermostat by turning clockwise. Adjust in a single increment of 30 degrees of a circle (the equivalent of 1 hour on a standard analog clock face). Wait 1 hour for results. If unsatisfactory, adjust another 30 degrees clockwise, wait, then asses results. Thermostat is located at back of unit. Hot water is not hot. • It takes 15-20 minutes after setup to dispense hot water. • Make sure the power cord is properly connected to a working outlet.
- Make sure energy saving switch is ON. Dispenser is noisy. • Make sure dispenser is positioned on a level surface. Water tastes bad. • Drain water from reservoirs and replace bottle with a fresh one. • Clean dispenser per Proper Care & Cleaning instructions. IMPORTANT: Do NOT Return Dispenser To Store. If you have a question or problem, please contact 855-VIVA-111 for assistance.

12Page 7LIMITED WARRANTY Electrotemp Technologies Inc., (“Vendor”) warrants to the original purchaser of this dispenser, and to no other person, that if this dispenser is assembled and operated in accordance with the printed instructions accompanying it, then for a period of one (1) year from the date of purchase, all parts in such dispenser shall be free from defects in material and workmanship. Vendor may require reasonable proof of your date of purchase from an authorized retailer or distributor. Therefore, you should retain your sales slip or invoice. The Limited Warranty shall be limited to repair or replacement of parts, which prove defective under normal use and service and which Vendor shall determine in its reasonable discretion upon examination to be defective. Before returning any parts, you should contact Vendor’s Customer Service Department using the contact information listed below. If Vendor confirms, after examination, a defect covered by this Limited Warranty in any returned part, and if Vendor approves claim, Vendor will replace such defective part without charge. If you return defective parts, transportation charges must be prepaid by you. Vendor will return replacement parts to original purchaser, freight or postage prepaid. The Limited Warranty does not cover any failures or operating difficulties due to accident, abuse, misuse, alteration, misapplication, improper installation or improper maintenance or service by you or any third party, or failure to perform normal and routine maintenance on the dispenser, as set out in the User’s Manual. In addition, the Limited Warranty does not cover damages to the finish, such as scratches, dents, discoloration or rust after purchase. The Limited Warranty is in lieu of all other express warranties.

Vendor disclaims all warranties for products that are purchased from seller other than authorized retailers or distributors. AFTER THE PERIOD OF THE ONE (1) YEAR EXPRESS WARRANTY, VENDOR DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. FURTHER, VENDOR SHALL HAVE NO LIABILITY WHATSOEVER TO PURCHASER OR ANY THIRD PARTY FOR ANY SPECIAL, INDIRECT, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. Vendor assumes no responsibility for any defects caused by third parties. This Limited Warranty gives the purchaser specific legal rights; a purchaser may have other rights depending upon where he or she lives. Some jurisdictions do not allow exclusion or limitation of special, incidental or consequential damages, or limitations on how long a warranty lasts, so the above exclusion and limitations may not apply to you. Electrotemp Technologies Inc. 406 Watline Avenue Mississauga, Ontario, Canada, L4Z-1X2 888-828-1426 www.electrotemp.com Warranty is void if electrical outlet is improperly wired to incorrectly sized circuit breaker or fuse, if not grounded properly, or wires do not have correct polarity.IMPORTANT: Do NOT Return Dispenser To Store. If you have a question or problem, please contact 855-VIVA-111 for assistance. 13Page 8名称：7LIECH-SC-SSFManual (VIVA) -English图号：5M008973X1技术要求：1、尺寸：143×210mm 2、单色印刷 3、产品符合Rosh要求 4、批量生产前一定要样品确认，不得擅自更改图纸。设计： 审核： 批准：版本号 修订内容 修订人 修订日期A罗亚勇2012-11-10对应铭牌，重量由13.1Kg更改为12.7Kg